

# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

### GENERAL SAFETY INSTRUCTION

- > This system must always be installed and commissioned by competent and qualified personnel.
- > The maintenance operations must be carried out exclusively by authorised and appropriately trained personnel.
- > For more information see the Technical Instruction Manual.

### GENERAL INTRODUCTION

NEW ATI enclosure integrates a new 4-pole changeover switch including electronics' control to meet standard IEC 60947-6-1. ATI enclosure is also available to standard IEC 61439-2.




### SWITCH MODULE INTERFACE

The new enclosure design allows switch module front panel direct access without opening of the enclosure for:

1. Visualization of the current changeover panel position.
2. Handle insertion in manual mode only to guarantee the transfer operation in any situation.
3. Padlocking mechanism in the 0 position (standard product) in manual mode (handle out of housing).
4. Functioning mode selection (Automatic/Manual).

\*Please note padlock not supplied with panel.




# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

### ELECTRONIC MODULE INTERFACE

The electronic module, also accessible from the front panel, includes:

1. Sources monitoring by Led: availability
2. Sources monitoring by Led: positions I-0-II
3. Transfer switches monitoring by Led (Functioning modes, Power supply, Fault)
4. Metering (Voltage (V) and Frequency (F) as standard), sequences' timers & settings display
5. Tests operations (On load & Off load)
6. Retransfer inhibit (RTI) Led and push button



# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL




### VISUALISATION

#### > Led

##### • Sources availability

Sources	Available	Not available
Mains	 Led on	 Led off
Genset	 Led on	 Led off

##### • Automatic Transfer Switch positions

Position I Mains	Position 0	Position II Genset
 Led on	 Led on	 Led on

##### • Operating modes

AUTO	MANUAL
 Led on	 Led on

##### • Lamp test



#### > Timers

Timer menu		
1FT	Loss of mains validation timer	(3 sec)
Once mains has disappeared, 1FT is started. If Mains comes back before 1FT ends, the commutation cycle is not started. (Delay on Gen start.)		
2AT	Genset stabilisation timer	(5 sec)
Generator needs to be stable during 2AT to allow transfer from Mains.		
1RT	Mains Return validation timer	(180 sec)
Once Mains power has returned 1RT is started. If Mains power disappears before 1RT ends, the load is not switched back to the Mains.		

##### • Test modes

On load	Off load
 Led on	 Led on

##### • Power supply

Active	Inactive	Blinking
 Software Error	 Power supply off	Product OK

##### • Fault synthesis

Active	Inactive	Blinking
 Product error	 Product OK	Lightning protection (Option)


2CT	Run on time timer	(180 sec)
Once the load is switched back from the Generator to the Mains, 2CT is started and the Generator will stop once 2CT is finished. (Allows generator cool down).		
ODT	Dead Band timer	(3 sec)
This timer is counted down before transferring the load from the Mains source to the Generator or vice versa.		

# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

### OPERATING

#### > Automatic



In Auto Mode:  

- Possible:
  - the automatic changeovers.
- Not possible:
  - to insert the handle
  - to pull the padlocking mechanism.


#### > Manual



In Manual Mode:  

- Possible:
  - to insert the handle and to operate manually.
- Not possible:
  - to operate electrically
  - to select the auto mode and to padlock if the handle is housing.

#### > Padlocking



In Padlocking Mode:  



- Possible:
  - to padlock in position 0 with a standard configuration.
- Not possible:
  - to operate electrically.
  - to select the auto mode
  - to insert the handle.

\*Please note padlock is not supplied with panel.

#### > Start/Stop group contact connection

Start Signal; Start & Stop (X & Y) should be connected to “control panel autostart signal”. Refer to control panel schematic for details.

# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

### FAULT FINDING GUIDE

Symptom	Step	Result
01 Automatic operations availability.	01 AUTO Led is on.	<p>&gt; NEGATIVE</p> <ul style="list-style-type: none"> <li>• Check that the switch has not been padlocked.</li> <li>• Check that the manual operating handle has been removed from housing.</li> <li>• Check that the selector has been put in AUT position.</li> <li>• Then consult your local dealer.</li> </ul> <p>&gt; POSITIVE</p> <ul style="list-style-type: none"> <li>• Go to the next step.</li> </ul>
	02 Fault synthesis Led is off.	<p>&gt; NEGATIVE</p> <ul style="list-style-type: none"> <li>• Led is blinking Check the lightning protection option and replace the fuse if damaged. Replace the fuses or the lightning protection module if damaged. Then consult your local dealer.</li> <li>• Led is on Try to reset the product (see the instructions below). Then consult your local dealer.</li> <li>• Reset Level 1</li> </ul> <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Level 2</p> <p>Switch off the power supply during 3 minutes by removing the power supply. Open site mains breaker and generating set breaker (position 0).</p> <p>&gt; POSITIVE</p> <ul style="list-style-type: none"> <li>• Go to the next step.</li> </ul>
	03 Power supply Led is blinking.	<p>&gt; NEGATIVE</p> <ul style="list-style-type: none"> <li>• Led is on: Try to reset the product (see the instructions above). Then consult your local dealer.</li> </ul> <p>&gt; POSITIVE</p> <ul style="list-style-type: none"> <li>• Go to the next symptoms.</li> </ul>
02 The mains availability.	01 Mains availability Led is on.	<p>&gt; NEGATIVE</p> <ul style="list-style-type: none"> <li>• Check lamp test.</li> <li>• Check that the mains return timer (1RT) is still not counting down.</li> <li>• Check that the mains protection system (breaker) is on (Position 1).</li> <li>• Then consult your local dealer.</li> </ul> <p>&gt; POSITIVE</p> <ul style="list-style-type: none"> <li>• Go to the next steps or symptoms.</li> </ul>
03 The genset availability (genset supposed started).	01 Genset availability Led is on.	<p>&gt; NEGATIVE</p> <ul style="list-style-type: none"> <li>• Check lamp test.</li> <li>• Check that the genset stabilisation timer (2AT) is still not counting down.</li> <li>• Check that the genset protection system (breaker) is on (Position 1).</li> <li>• Then consult your local dealer.</li> </ul> <p>&gt; POSITIVE</p> <ul style="list-style-type: none"> <li>• Go to the next steps or symptoms.</li> </ul>

# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

### FAULT FINDING GUIDE

Symptom	Step	Result
04 The product doesn't transfer to the genset in case of mains failure or test on load.	01 AUT Led is on & Fault synthesis Led is off & Power supply Led is blinking.	> NEGATIVE • Go to symptom 01.
		> POSITIVE • Go to the next step.
	02 Genset is started.	> NEGATIVE • Check that the mains failure timer (1FT) is still not counting down. • Check the genset control panel is set to the auto position. • Then consult your local dealer.
		> POSITIVE • Go to the next step.
	03 Genset availability Led is on.	> NEGATIVE • Go to symptom 03.
		> POSITIVE • Consult your local dealer.
05 The product doesn't transfer to the mains in case of mains return or test on load end.	01 AUT Led is on & Fault synthesis Led is off & Power supply Led is blinking.	> NEGATIVE • Go to symptom 01.
		> POSITIVE • Go to the next step.
	02 Mains availability Led is on.	> NEGATIVE • Go to symptom 02.
		> POSITIVE • Go to the next step.
	03 Retransfer inhibit (RTI) function is off.	> NEGATIVE • Push the ESC push button
		> POSITIVE • Consult your local dealer.
06 Genset keeps on running after mains restores and switch retransfers to the mains position.	01 AUT Led is on & Fault synthesis Led is off & Power supply Led is blinking.	> NEGATIVE • Go to symptom 01.
		> POSITIVE • Go to the next step.
	02 The run on time timer (2CT) is still counting down (visible on the display).	> NEGATIVE • Check the genset control panel is set to the auto position. • Then consult your local dealer.
		> POSITIVE • Wait for the 2CT end.

# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

### FAULT FINDING GUIDE

Symptom	Step	Result
07 Switch manual operations are not possible.	01 Manual Led is on.	> NEGATIVE • Turn the selector to the manual position.
		> POSITIVE • Go to the next step.
	02 The manual handle introduction is possible.	> NEGATIVE • Check that the switch has not been padlocked.
		> POSITIVE • Go to the next step.
	03 The manual operation is possible.	> NEGATIVE • Check the required rotation of the switch. • Check that the sufficient torque has been applied. • Then consult your local dealer.
		> POSITIVE • Goal reached.
08 Switch padlocking operations are not possible.	01 Manual Led is on.	> NEGATIVE • Turn the selector to the manual position.
		> POSITIVE • Go to the next step.
	02 Possible to pull the padlocking mechanism.	> NEGATIVE • Check that the product is in the 0 position for standard product. • Check that the manual operating handle has been removed from housing. • Then consult your local dealer.
		> POSITIVE • Goal reached.

# ATI Transfer Panel

## OPERATORS INSTRUCTION MANUAL

---

### CONDITIONS OF USE



#### Hygrometry:

- 80% humidity without condensation at 55 °C
- 95 % humidity without condensation at 40 °C



#### Temperature:

- -10 +40 °C without de-rating
- +40 +65 °C with de-rating\*



#### Ingress Protection:

- Enclosed: IP41
- Loose: IP2x



#### Storage:

- Temperature -20 to +40 °C
- Period: 1 year max



#### Power input:

- $V_n = 230\text{Vac} \rightarrow [208 / 277 \text{Vac}]$

\* For de-rating information see Instruction Manual.

---

### INSTRUCTION MANUAL REFERENCE

> For detailed instruction & installation guide, please refer to:

